

7-0130-0(W/B) Canopy Guide set

The Canopy guide set consists of:

1	ea	7-0130-1 left guide	
1	ea	7-0130-2 right guide	
4	ea	NAS514P832-20P	screw
4	ea	NAS1149FN816P	washer
4	ea	MS2104NN08	nut

Intended uses are RV7 and RV9 tip up canopies. These will fit the RV6 however the cutout for the canopy deck is cut about ¼” too much. It requires no modifications to use, but if this is objectionable, we would be happy to take them back.



Install:

Note that there is a right and left guide. The bottom edge is at an angle to match the RV7 or 9 roll bar. Due to individual construction the angle may vary a bit from the guide. Sand the bottom of the guide to fit your airplane if you wish.

Clamp the guide into place and match drill the holes with a .166 inch drill. The guides may be slightly warped from machining. Just clamp them flat before drilling.

The washers and nuts are accessible through the access hole in the back of the roll bar.